



Is Your Camera Compatible with the Syrp Genie ?

CANON

EOS 1000D | 650D | 600D | 500D | 550D | 450D | 400D | 350D | 70D | 60D | 33 | 50 | 50D | 40D | 30D | 20D | 10D | 7D | 6D | 5D | 5D | 1D series | 1Vseries | EOS 3 | D2000

CONTAX

645 | N1 | NZ | N Digital

FUJIFILM

S5 Pro | S3 Pro

KODAK

DSC-14n

KONICA MINOLTA

DIMAGE a2 | a1 | 9 | 7H | 7i | 7 | 5 | 4 | 3 | DYNAX 7D | 5D

LEICA

DIGILUX2 | DIGILUX3

NIKON

D1 Series | D2 series | D3 series | D4s | Df | D800 | D700 | D600 | D300 | D200 | N90s | F5 | F6 | F100 | F90 | F90X | DSLR D90 | D3200 | D5000 | D7100 | D7000 | DSLR D80 | D70s

OLYMPUS

E520 | E510 | E420 | E410 | E300 | SP-570 UZ | SP-560 UZ | SP-550 UZ | SP-510 UZ | E1 | E3 | E5 | E10 | E20 | E30 | EP1 | EM1 | EM5 | EM10 |

PANASONIC

Leica DigiLux 2 | DigiLux 3 | V-Lux 1 | V-Lux 2 | V-Lux 3 | Panasonic FT 2 | FZ100 | FZ15 | FZ150 | FZ20 | FZ200 | FZ30 | FZ50 | G1 | G10 | G2 | G3 | G5 | GF1 | GH1 | GH2 | GH3 | GH4 | GX1 | GX7 L1 | L10 | LC1 | TS2

PENTAX

istD | DS | DL | DSL | K100D | K110D | K10D | K200 | K20D | K5

SAMSUNG

GX-1L | GX-1S | GX-10 | GX-20

SONY

DSLR a7 | a7r | a7s | a57 | a900 | a700 | a350 | a300 | a200 | a100 | a100K | a580 | a560 | a550 | a500 | a450 | a350 | a99 | a77 | a3000 | a5000 | a6000

SONY IR-MIXED

Sony NEX 5 | NEX 5N | NEX 5T | NEX 7 | NEX 6 | Sony a7 | a7r | a7s | a3000 | a5000 | a6000 |

Nikon 1 series | Includes compatibility with other cameras with infrared receivers from Canon, Nikon, Minolta, Panasonic, Sony and Olympus. **Please check your camera specs to confirm infrared capability.**

IF YOUR CAMERA IS NOT LISTED PLEASE CONTACT SeeSense

Rev. 1.001.0714 E.&O.E.

Email: Nigel@SeeSense.eu

Mob: 00 44 7967 445829

Web: www.SeeSense.eu

SeeSense s.r.o. Slovakia

Tel: 00421 917 163 367

PO Box 42, Kezmarok, 06001,
Slovak Republic

SeeSense United Kingdom

Tel: 00 44 203 468 2250

55 Manor Close, Harpole, NN74BX
UK



Syrp Genie Camera Cable Plug Selector

1C - CANON

Canon EOS 1100D(T3) | 1000D (XS) | 650D(T4i) | 600D(T3i) | 550D(T2i) | 500D (T1i) | 450D (XSi) | 400D (XTi) | 350D(XT) | 300D | 300V | 300 | 70D | 60D | 60Da | 50E | 50 | 33 | 30 | 3000
Canon Powershot G1X | G10 | G11 | G12
Contax N Digital NX | N1 | 645 / Samsung GX 1L | GX 1S | GX-10
Pentax K100D | K110D | K10D | K20D | K200D*ist DS2 | K-5 |
*ist D | *ist Ds | *ist *ist DL MZ-6 | ZX-L | MZ-L | *ist DL2

3C - CANON

Canon EOS 7D | 50D | 40D | 30D | 6D | 5D | 20D | 10D | 5D Mark III | 5D Mark II | 1D X | 1D C | 1D Mark IV | 1D(s)Mark III | 1D(s)Mark II(N)

1N - NIKON

Nikon D1 | D1X | D2 | D2H | D2HS | D2X | D2XS | D800E | D800 | D700 | D300S | D300 | D200 | D4 | D4s | D3X | D3
Fujifilm S5 Pro | S3 Pro
Kodak DCS Pro 14n

2N - NIKON

Nikon D80 | D70s

3N - NIKON

D7000 | D5300 | D5200 | D5100 | D5000 | D3200 | D3100 | D600 | D610 | D90 | Df |

3L - OLYMPUS

| E600 | E520 | E510 | E450 | E420 | E410 | EM1 | EM5 | EM10 | EP3 | EP2 | EP1 | E30 | E3 | SP-570UZ | SP-560UZ | SP-550UZ | SP-510UZ

1P - PANASONIC

Panasonic DMC-FZ20 | DMC-FZ30S | L1 | GH1 | GH2 | GH3 | GH4
DIGILUX3 | DMC-FZ20k | DMC-FZ50K | DIGILUX 2 | DMC-GF1 | DMC-FZ100 | DIGILUX2 | DMC-FZ20S | DMC-FZ50S | DIGILUX 3 | DMCG2 | DMC-FZ30 | DMC-FZ50 | L-10 | DMC-G3 | DMC-FZ30K | LC-1 | DMC-G1 | DMC-G10

1S - SONY

A900 | A850 | A700 | A580 | A550 | A500 | A450 | A350 | A300 | A200 | A100 | A99 | A77 | A65 | A57 | A55 | A35 | A33 |

IR - MIXED

Sony a7 | a7r | a7s | a3000 | a5000 | a6000 | Sony NEX | Nikon 1 Series | As well as other brands with an infrared receiver, Canon, Nikon, Minolta, Panasonic, Sony, Olympus.

Rev. 1.001.0714 E.&O.E.

Email: Nigel@SeeSense.eu

Mob: 00 44 7967 445829

Web: www.SeeSense.eu

SeeSense s.r.o. Slovakia

Tel: 00421 917 163 367

PO Box 42, Kezmarok, 06001,
Slovak Republic

SeeSense United Kingdom

Tel: 00 44 203 468 2250

55 Manor Close, Harpole, NN74BX
UK